

**Customize your terminal**  
The customization functions of the telephone are accessed from the **Menu** page.

**Modifying your personal code**

reach the "menu" page

Settings

My phone / My options

follow informations displayed on the screen

Password

**Lock / unlock your telephone**

reach the "menu" page

LOCK

your telephone is locked/unlocked

depending the displayed informations, enter your password or confirm

**Adjusting the audio functions**

reach the "menu" page

SETTINGS

My phone

adjust ringing (melody, volume, mode...) by following instructions displayed on the screen

**Adjusting screen brightness**

reach the "menu" page

Settings

My phone

increase or decrease the contrast

adjust the contrast by consecutive presses

**Display and display keys**  
Contains several lines and pages providing information on calls and the functions accessible via the 6 keys associated with the words on the screen.

Transfer icon: pressing the key next to this icon allows you to program or change the transfer function.

Headset connected.

Silent mode activated.

Appointment programmed.

Telephone locked.

Display keys: pressing a display key activates the function shown associated with it on the screen.

**Navigation**

OK key: used to validate your choices and options while programming or configuring.

Left-right navigator: used to move from one page to another.

Up-down navigator: used to scroll through the content of a page.

**Welcome screens**

Back/Exit keys: to return to previous menu (short press) or return to first screen (long press); during a conversation, provides access to welcome screens (Menu, Info, ...) and to return to the conversation icon screens.

Menu page: contains all functions and applications accessible via the keys associated with the words on the screen.

Perso page: contains call line keys (following supervision of calls) and programmable call keys.

Info page: contains information on the telephone and the status of its functions: name, telephone number, number of messages, activation of transfer function, appointment reminder, etc.

**Call display**

Incoming call.

Call in progress or outgoing call.

Call on hold\*.

If you get two calls at the same time, you can switch from one call to the other by pressing the display key associated with each call.

Left-right navigator: used to check calls.

OK key: used to answer the call checked.

**Function keys and programmable keys**

Guide key: used to obtain information on functions of the "menu" page and to program key of the "perso" page.

Messaging key: to access various mail services: if the key flashes, a new voice message or a new text message has been received.

"Redial" key: to access the "Redial" function.

Programmable key (F1 and F2 keys):  
It when the function associated with this key is activated.

**Handset**

Adjust the tilt of the screen

**Indicator light**

- Flashing green: incoming call.
- Flashing orange: alarm.

Alphabet keypad

Socket for connecting headphones or a Hands-free / Loudspeaker unit.

**Audio keys**

Hang-up key: to terminate a call.

Hands-free/Loudspeaker Key: to make or answer a call without lifting the receiver.

- Lit in hands-free mode or headset mode (short press).
- Flashing in loudspeaker mode (long press).

Intercom/Mute key

- During a conversation: press this key so that your correspondent can no longer hear you.
- Terminal idle: press this key to answer calls automatically without picking up the receiver.

To adjust the loudspeaker or handset volume up or down.

**Extension unit**

An extension unit can be fitted to your telephone. This provides additional keys which can be configured as function keys, line keys, call keys, etc.

To affix labels: push the holding strip of the unit backwards to you and fit it. Install the label under the keypad, in the housing designed for, and place the keypad back into position.

