

## Handset

Adjust the tilt of the screen



Solve for connecting headphones or a Hands-free / Loudspeaker unit

Alphanumeric keypad

- Indicator light**
- Flashing green: incoming call.
  - Flashing red: alarm.

- Display and display keys**  
Contains several lines and pages providing information on calls and the functions accessible via the 10 keys associated with the words on the screen.

- Transfer keys:** pressing the key next to this icon allows you to program or change the transfer function.
- Headset connected.**
- Silent mode activated.**
- Display keys:** pressing a display key activates the function shown associated with it on the screen.

- Appointment programmed.**
- Telephone locked.**

## Navigation

- OK key:** used to validate your choices and options while programming or configuring.

**Left-right navigator:** used to move from one page to another.

**Up-down navigator:** used to scroll through the content of a page.

- Back/Exit key:** to return to previous menu (short press) or return to first screen (long press); during a conversation, provides access to welcome screens (Menu, Info, ...) and to return to the conversation log screens.

## Welcome screens



- Menu page:** contains all functions and applications accessible via the keys associated with the words on the screen.
- perso page:** contains call log keys and programmable call keys.

**Info page:** contains information on the telephone and the status of its functions: name, telephone number, number of messages, activation of transfer function, appointment reminder, etc.

## Audio keys

**Hang-up key:** terminates a call.

**Hands-free/Loudspeaker Key:** to make or answer a call without lifting the receiver.

- Lit in hands-free mode or headset mode (short press).
- Flashing in loudspeaker mode (long press).

## Intercom/Mute key

- During a conversation: press this key so that your correspondent can no longer hear you.
- Terminal idle: press this key to answer calls automatically without picking up the receiver.

To adjust the loudspeaker or headset volume up or down.

## Extension unit



An extension unit can be fitted to your telephone. This provides additional keys which can be configured as function keys.

To affix labels: push the holding strip of the unit backwards to you and lift & install the label under the keypad, in the housing designed for, and place the keypad back into position.

## Customize your terminal

The customization functions of the telephone are accessed from the Menu page.

## Modifying your personal code




reach the "menu" page



## Lock / unlock your telephone



reach the "menu" page




depending the displayed informations, enter your password or confirm

## Adjusting the audio functions



reach the "menu" page



adjust ringing (melody, volume, mode...) by following instructions displayed on the screen

## Adjusting screen brightness (Alcatel 4038)



reach the "menu" page



increase or decrease the contrast



adjust the contrast by consecutive presses

## Function keys and programmable keys

- Guide key:** used to obtain informations on functions of the "menu" page and to program key of the "perso" page.

- Messaging key to access various mail services:** if the key flashes, a new voice message or a new text message has been received.

- "Redial" key:** call back the last number dialed.

- Programmable key (F1 and F2 keys):** is when the function associated with the key is activated

## Using your telephone

### Identify the terminal you are on

The number of your telephone is displayed on the "Info" page.



Access the Info page using the navigator.

### Making a call



lift the receiver



hands free



programmed line key



dis directly the number for your call

To make an external call, dial the outside line access code before dialling your correspondent's number.

### Receiving a call



lift the receiver



hands free



press the key next to the "incoming call" icon

### Redialling



last number redial

### Make a call-back request to a busy number



the number you are calling is busy



hang up

### Voice message service

#### Consulting your voice mailbox

if the key flashes, a new voice message or a new text message has been received.



follow informations displayed on the screen

press the key next to "consult voice or text message"

## Divert your calls to another number

### Divert your calls to another number



press the key associated with the type of diversion required (immediate, if busy, if no reply, etc.)



dial the destination number

press the ok key if programming is not automatically recorded



### Diverting calls to your voice mailbox



press the key associated with "divert to voice mailbox"



press the ok key if programming is not automatically recorded

### When you return, cancel all diversions



press the key next to "cancel or deactivate the diversion"



if necessary, confirm cancellation of the diversion

## Directory

### Using call by name



enter the first letters of the name



select the name from the displayed list



make the call

### Program your call keys



press a call key or a programmable key (F1 or F2), either directly or via the **1** key



follow informations displayed on the screen

### Make calls via your programmed call keys



access the perso page using the navigator



find the correspondent you want to call from the programmed call keys



call the chosen correspondent

## During a conversation

### Sending DTMF signals

During a conversation you sometimes have to send DTMF signals, such as with a voice server, an automated attendant or a remotely consulted answering machine. The function is automatically cancelled when you hang up.



during a conversation



Send DTMF



to activate

### Calling a second person during a conversation

During a conversation, to call a second person:



dial directly the number for your call

the first call is on hold

### Transferring a call

During a conversation, to transfer the call to another number:



number to be called

### Three-way conference

During a conversation, a second call is on hold.



three-way conference  
cancel conference and return to first correspondent.

hang up on all correspondent.

### Guarantee and clauses

This document describes the services available on telephones Alcatel 4028-4079 connected to an Alcatel OmniPCX Office or Alcatel OmniPCX Enterprise system. For more information, please consult the User Guide for your 4028 (IP set) or 4079 (digital set). Contact your installer. Warning: never place your telephone in contact with water. To clean your telephone, you may however use a damp soft cloth. Never use solvents (trichloroethylene, acetone, etc.) which may damage the plastic parts of your telephone. Never spray it with cleaning products. Erpicorp may retain magnetic objects.

The wording is not contractual and may be subject to change. Some functions of your telephone are controlled by a software key and the configuration of the unit.

EC: We, Alcatel Business Systems, hereby declare that we assume the Alcatel 4028 or 4079 product to be compliant with the essential requirements of Directive 1990/269/EEC of the European Parliament and Council. A copy of the original of this declaration of compliance can be obtained from your installer.

Alcatel Business Systems, in keeping with its policy of constant product improvement for the customer, reserves the right to modify product specifications without prior notice. Copyright © Alcatel Business Systems, 2004. All rights reserved.



3 6119 00385 A A 010447